

## CableClam Installation Instructions

PN 1001 / 1002 / 1003

1. Drill seal with a sharp drill the same size as the cable. Keep the hole wet during drilling. The hole will be slightly smaller than the cable.
2. Use a sharp razor knife to slit the seal from its edge to the center hole
3. Fasten the deck ring and gasket to the surface.
4. Slip the compression ring onto the cable. Insert the cable through the slit of the seal. Press the seal into the compression ring.
5. Screw the compression ring to the deck ring by tightening each screw a few turns at a time. Do not overtighten the screws.

