

Printing Instructions

1. Place a 11 x 17 sheet in the copy machine.

2. Print

2. Cut along marked Line before Folding

Cut here

Forward
(Bow)

We recommend drilling a 3/16" (4.8mm) hole for the Light Wire before cutting the Mounting Hole.

Mounting screws
8.28" (21.03 cm)
Bolt Circle

Ⓞ

Compass centerline
should be parallel to
the centerline of the
Boat.

Mounting hole
Cut along this line
7 1/4" (18.41 cm)

Outside Dimension
9.00" (22.86 cm)

RITCHIE[®]

Mounting Template for
the F-600's & SF-600's

Part # 6G-0070
Rev A 5/10