MARLINCO

STAINLESS STEEL SPOT/FLOOD LIGHT

INSTALLATION & OPERATION INSTRUCTIONS

(ITEM #'S: 22040A, 22044)



IMPORTANT! READ THESE INSTRUCTIONS BEFORE INSTALLING AND USING THIS PRODUCT. KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.

Description

The Marinco 22040A spot/floodlight uses a high-powered, dual focus sealed beam bulb. Its penetrating 72,000 candlepower beam can illuminate objects up to a 1/4 mile away, and its 30,000CP flood light is perfect for docking or picking up a mooring. Constructed of stainless steel or chromed brass, it will give years of service with no maintenance required. The model 22040A comes complete and ready to install, with an easy-to-use "joystick" remote control system and 10 feet of control cable.

This spot/floodlight can rotate 350° and move up and down through an 70° arc. A second control station can be installed by using an optional #22018A second station control kit, and an additional control cable.

Tools for Installation

Tools and additional materials required:

- · Electric drill with 2-3/4" hole saw bit
- 5/8", 1/8" and 3/32" drill bits
- · Phillips-head screwdriver
- (3) #10 x 3/4" SS phillips pan-head selftapping screws (or #10 machine screws, lock washers and nuts.)
- Non-silicon sealant (StarBrite® Boat Caulk #83801 or equivalent)
- (2) # 8 x 3/4" SS pan head self-tapping screws
- ½" cable clamps with screws (to fasten control cable to interior surfaces)

Mounting the Spotlight

Select a flat, smooth surface on which to mount the spotlight. Be sure that you will
have access to the underside of the chosen location, and that you can drill holes
there without damaging existing wiring or structures. Avoid locations where lines,
anchor, sails or other hazards might damage the light.

Note: Mounting the light as far forward as possible can help to reduce reflected glare when the light is in use.

- 2) Mark the locations of the three base mounting holes and center the wire harness hole onto the mounting surface with a pencil.
- 3) Drill 1/8" pilot holes into the mounting surface at the marked points.
- 4) Place the mounting gasket on the base of the spotlight, making sure that the harness exits through the center hole of the gasket.
- 5) Feed the wires from the base of the spotlight through the center hole in the mounting surface. A small amount of non silicone sealant can be applied to the pilot holes and around the wire harness where it penetrates the mounting surface.
- 6) Place the light on the mounting surface, and fasten the spotlight securely using three #10 self tapping Phillips pan-head screws. Do not over tighten the fasteners.

Mounting the Control Panel

- Select a convenient mounting location for the control panel. Be sure you will have
 access to the area behind the location, and can drill holes there without damaging
 existing wiring or structures. Do not place the control where it could interfere with
 the safe operation of the vessel or vehicle. Avoid mounting the control panel on a
 surface exposed to the elements or spray.
- 2) Drill two 1/16" pilot holes for the hole saw at the locations shown on this template. Be sure they are level and spaced 13/16" apart.

CAUTION: Always wear eye protection when using power tools!


- 3) Next, use the hole saw to cut a 2-3/4" hole.
- 4) Feed all the wires through the center hole. Test fit the control panel into the hole. Use a file to enlarge the hole if necessary.
- 5) Use a pencil to mark the locations of the two small holes in the panel onto the mounting surface. Remove the control panel, then drill a 3/32" pilot hole at each of the marked locations.

6) Apply a small amount of sealant, (such as StarBrite® Boat Caulk #83801), to the back of the control panel face plate. Fit the control panel into the hole, and fasten the control panel onto the surface with two # 8 x 3/4" Phillips pan head self-tapping screws

Installing the wiring harness

Find a path for the wire harness from the spotlight to the control panel. Avoid sharp edges and hot surfaces. Fasten the cable securely in place along its' length using 1/2" insulated cable clamps. Note: To make it easier to install the wire harness through railings or conduits, do not attach the male plug connector to the spotlight's 7-wire harness until after the harness is secured in place.

Placement of light cable wires into connector:




Electrical Connections

This spotlight requires a source of 12 volt DC power that is capable of carrying up to 10 amps of current. For best results, run two new wires from the red (+) positive and black (–) negative power wires of the control panel directly to the main 12 volt DC accessory panel.

Install the brown, plastic male plug connector onto the 7-wire harness by pushing each wire's brass connector into one of the 9 openings in the back of the plastic male connector. You will hear a "click" as each brass connector locks into place.

Complete the wiring connections as shown here:



Specifications

Dimensions	4-1/2"W x 9-1/2"H x 7-1/2"D
Operating voltage	12-14 volts DC
Current consumption (bulb)	7.5 amps

LIMITED WARRANTY

For customer convenience, Marinco warranty is located at marinco.com/limitedwarranty.

Marinco is a proven industry leader, with a Global network of sales, distribution, and service. Product concerns as related to Form, Fit and Function may be submitted online at marinco.com/limited-warranty.

Please fill in the online form titled Marinco RMA Request and we will contact you with any questions or concerns.

